



MARINE ROADGUARD OPERATOR MANUAL

FOR WINDSHIELD PROTECTION SYSTEM (WPS)

SAFETY FIRST

Your safety and the protection of your vessel are our top priorities. Always follow the instructions in this manual.

CAUTION

Failure to follow the cautions in this manual may result in damage to the product, your vessel, or other property. Such damage is not covered under the limited warranty.

WARNING

Failure to follow the warnings in this manual may result in personal injury, property damage, or death. Improper use, installation, handling, or storage can void the limited warranty and release the manufacturer from all liability.



LIMITED WARRANTY & LIABILITY PROTECTION

The Marine RoadGuard WPS is warranted to be free from defects in materials and workmanship for a period of 1 year from the date of purchase. This warranty does not cover damage caused by misuse, improper installation, failure to follow instructions, improper care, modification, or storing the product while wet, damp, or in extreme conditions. Proper installation, use, care, and storage as outlined in this manual are required to maintain limited warranty coverage. The manufacturer shall not be liable for any incidental, consequential, or special damages arising from the use or inability to use this product.



OPERATING INSTRUCTIONS

1. Component Identification	2	6. SPI Removal	6
2. Unpacking the System	3	7. Repacking the System	7
3. Allow SPI to Lay Flat (Relax)	3	8. Cleaning & Maintenance	8
4. Install SPI in WPS	4	9. Storage Requirements	9
5. WPS Installation	5	10. General Best Practices	10



QUICK SETUP GUIDE

Marine RoadGuard Windshield Protection System (WPS)



1 UNROLL & RELAX SPI

- Remove all eight (8) transport straps from the rolled system.
- Unroll the WPS, SPI foam, and HDPE layers.
- Lay the SPI foam and HDPE flat on a clean, dry surface.
- Allow the SPI materials to relax and flatten before insertion into the WPS.

WARNING:

Do not force tightly rolled SPI materials into the WPS. Damage caused by improper handling may void or limit warranty coverage.



2 INSTALL SPI IN THE WPS

- Open the WPS.
- Insert the laid-flat SPI (foam and HDPE) into the WPS.
- Center the SPI so it sits evenly within the WPS.



3 INSTALL TRANSPORT STRAPS

- Install four (4) transport straps on the left-side grab/anchor post.
- Install four (4) transport straps on the right-side grab/anchor post.
- Place the rectangular ring around the post.
- Feed the 2-inch hook-and-loop webbing through the ring and tighten.



4 POSITION THE WPS

- Remove or lift windshield wipers out of the way before installation.
- With a helper, position the WPS against the windshield.
- Ensure the CLOSED VELCRO FLAP side faces inward against the windshield glass.
- Center the shield evenly.

CAUTION:

Ensure no sand, dirt, or debris is trapped between the WPS and vessel surfaces.



5 SECURE & TIGHTEN

- Start by loosely attaching the top straps on both sides.
- Continue downward evenly while maintaining centered alignment.
- Gradually tighten all straps evenly.
- Do not overtighten.



6 AFTER TRANSPORT

- Remove the WPS after transport.
- Allow all components to fully dry before storage.
- Never store damp or wet components.
- Store indoors in a clean, dry environment.



READ THE OPERATOR MANUAL BEFORE USING THIS QSG.

This Quick Setup Guide (QSG) does not replace the full operator manual.



TRANSPORT USE ONLY • REMOVE AFTER TRANSPORT

READ FULL OPERATOR MANUAL BEFORE USE